

STEEDA

1999-2000 Rear Wing

Installation Instructions

1. Remove the original rear wing. If your car did not come with a wing from the factory skip steps 2 and 3 and see the special instructions below.
2. Plug the two front mounting holes on each side of the trunk lid with the supplied plugs: Apply a small dab of black silicone sealer around the hole to prevent leaks and push the plugs in from the top. From the underside of the trunk lid, push the supplied washers over the end of the plugs. This will keep them from coming loose.
- 3 The new wing is bolted to the car using the rear holes in the trunk lid for the front bolts of the wing. Line up the wing using the front bolts. Mark and drill the holes for the rear bolts. (There is a small round flat spot on the underside of the trunk lid where the rear bolt will be centered).
4. Paint the wing to the color of your choice. Before bolting it to the car apply a small amount of silicone gasket maker around the hole to prevent leaks.

If your Mustang did not come with a wing from the factory - Or if it has the special 30th anniversary appearance package rear wing - you will need to drill four holes to mount the wing. The wing attaches near the very back of the trunk lid. There are several small round flat spots (about an inch across) on the underside of the trunk lid, near the left and right edges. The bolts for the wing should go approximately through the center of the two most rearward round flat spots.

STEEDA AUTOSPORTS
1351 NW Steeda Way
Pompano Beach, FL 33069

954-960-0774