



## 2012+ Focus Dead Pedal

Instructions for part #555-1265



1. Set the parking brake.
2. Place the dead pedal in the desired position and mark the holes for drilling. Figure 1.
3. Remove the lower door frame trim panel as shown in figure 2. Pull up carefully from the edges, specifically the locations noted. Figure 2.
4. Carefully, pull the kick panel out away from the body enough to get the carpet out from underneath it. Figure 3.
5. Fold back the carpet from the dead pedal area of the floor, and out from underneath the kick panel. Figure 4.
6. Using a 13/64" drill bit, drill through the carpet and backing, the four holes that were previously marked. **Note: Make sure the drill bit being used is very sharp, and be mindful when drilling through the carpet to make sure the bit goes through smoothly and doesn't snag any carpet.**
7. Secure the dead pedal to the carpet with the provided 10-32 screws and nuts. Figure 5. **Note: The kit comes with 2 different lengths of screws and a set of washers to secure the pedal, depending on preference.**
8. Reinstall in reverse order.

