

# Steeda S197 Mustang Idler Pulley Installation

555-3349

## Parts List

Qty.	Description
2	Billet Idler Pulleys
2	Washers
2	Bolts

## Installation

1. Rotate the tensioner arm with a  $\frac{1}{2}$ " drive wrench or breaker bar and release the accessory drive belt from the alternator pulley (installation shown on supercharged vehicle but naturally aspirated engines are similar).
2. On the driver's side, remove the nut holding the ballast resistor and coolant hose bracket. Slide these 2 items off of the stud.
3. Remove the idler pulley from each side.
4. With the snap ring facing the front of the car, install a billet idler pulley onto each side of the engine. Secure each with a bolt and washer and tighten.
5. Re-attach coolant hose bracket and ballast resistor and secure/tighten with factory nut.
6. Route accessory drive belt appropriately and re-tension with the belt tensioner.

