  
**STEEDA®**  
**Steeda Focus ST Clutch Line**  
Installation Instructions: 555-7017



**Tools Needed**

1. 7mm socket
2. 10mm socket
3. 10mm wrench
4. 11mm wrench
5. 13mm socket
6. Small flathead screwdriver

**Installation**

1. Open and prop up hood in order to begin.
2. Remove the plastic engine cover by pulling up on its face.
3. Remove the factory air box and air filter.
4. Unclip the factory wiring loom from the front of the battery box.
5. Disconnect the power and ground cables from the battery box using the 10 & 13mm sockets.




Figure 1

6. Remove the front wall from the battery box and place it aside.
7. Remove the battery.
8. Three 10mm bolts hold the factory battery box in place, remove them and then pull out the battery box and place it aside.

9. Locate the clutch line, place catch can or oil pan underneath the clutch line to catch any fluid which may spill.
10. Using a small flathead screwdriver, remove the hairpin clips on the front and rear clutch line connection points.




Figure 2



Figure 3

11. Remove the stock mounting hose grommet from its bracket.



Figure 4

12. Disconnect the factory clutch line.
13. Install the Steeda clutch line making sure to route it above the shift cable and below the brake lines, re-install the hairpin clips which held the factory line in place.
14. Using the factory bleed screw (*figure 3*) bleed the clutch line until no air is left in the system.
15. Re-assemble factory components in reverse order.
16. Enjoy!