

# GRILL DELETE KIT INSTALLATION INSTRUCTIONS

Part # 555-0205

- 1) Remove the plastic blind rivets from the top of the grill. Unscrew the center part enough to get a grip on it and then pull it out. Then take a screwdriver and pry the outer half out of the hole.
- 2) Remove the two blind rivets from the front fascia, (one on each side of the grill).
- 3) Carefully pull the grill and upper part of the fascia forward so you can reach the four bolts on the bottom of the grill. Remove the bolts with a 7mm wrench. Remove the grill from the car.
- 4) Remove the two large plastic push pins in the lower corners of the inner grill insert by prying them out with a large screwdriver.
- 5) Remove the inner grill insert from the car
- 6) Install the new inner grill insert on the car with the two push pins and two blind rivets.
- 7) Wash the section of the fascia that was behind the old grill. You want to remove the wax so the adhesive for the new grill molding will stick. Dishwashing liquid such as Palmolive works good for this.
- 8) Set the new outer grill molding in place to make sure you know exactly where it will go. Then remove the molding and peel the backing off of the double-sided tape.
- 9) Set the outer molding back in position and install the blind rivets at the corners to secure it to the fascia.
- 10) Once the corners are secure in the proper location, push down and across the front of the molding to make the double-sided tape stick to the fascia.
- 11) Attach the new horse emblem to the grill insert with the self-tapping screws provided. Make sure the bottom of the bracket gets hooked into the bumper support.

