


Aeroforce 5V Regulator Connections




RED-----SWITCHED 12VDC (Use a fused circuit or “Add-a-Circuit” available at most auto parts stores for easy and clean installation)

BLK-----GROUND

GREEN-----+5VDC (TO SENSOR)

BLK-----GROUND (TO SENSOR)

Aeroforce 5V Regulator Connections



RED-----SWITCHED 12VDC (Use a fused circuit or “Add-a-Circuit” available at most auto parts stores for easy and clean installation)

BLK-----GROUND

GREEN-----+5VDC (TO SENSOR)

BLK-----GROUND (TO SENSOR)